

Type Designation	Maker or Originator	CV No. (or nearest in brackets)	Type Designation	Maker or Originator	CV No. (or nearest in brackets)	Type Designation	Maker or Originator	CV No. (or nearest in brackets)
6F6GI	USA	CV731	6K6GI	USA	CV1940	6R4	Mullard	CV1865
6F6GI/G	USA	CV731	6K6GI/G	Ferranti		6R6G	USA	CV1960
6F7	USA	CV1915	6K7	USA	CV1940	6R7	USA	CV1963
6F8G	USA	CV1917		USA	CV1942	6R7G	USA	CV1962
	Ferranti			Ferranti			Ferranti	
	Cossor			Cossor			Tungfram	
6F10	IRC	CV8382	6K7G	USA	(CV1941)	6R7GI	USA	CV1964
6FR10	IRC	CV8383		Tungfram			USA	
6F11	Mazda	CV1901		Cossor		6R7GI/G	USA	CV1964
6F12	Mazda	(CV138)		Mullard		6S7	USA	CV1975
6F60	IRC	CV8719	6K7GI	Ferranti	(CV1943)	6S7G	USA	CV1974
6FR60	IRC	CV8720		USA		6SA7	USA	CV1966
				Ferranti			Ferranti	
				Tungfram			Cossor	
				Cossor			USA	
6F13	Mazda	CV1839	6K8	USA	CV1945	6SA7GT	USA	CV1967
6F14	Mazda	CV1919		Cossor			USA	
6F17	Mazda	(CV416)		Ferranti		6SA7GI/G	USA	CV1967
6F17S	STC	CV11025		USA		6SA7Y	USA	CV3974
6F32	SIC	(CV1116)	6K8G	Ferranti	(CV1944)	6SC7	USA	CV1969
6F33	SIC	(CV329)(o), (CV2209)		USA		6SC7GI	USA	CV1970
				Tungfram		6SD7GI	USA	CV865
6F40	IRC	CV10182	6K8GI	USA	CV1946		USA	
6G6G	USA	CV1926		Ferranti		6SF5	USA	CV1972
	Ferranti			Tungfram		6SF5GI	USA	CV1973
	Plessey	(CV7029)				6SG7	USA	CV1978
6G8	RCA	CV856	6K25	Mazda	(CV2217)		Ferranti	
6G8G	USA	CV1930	6L5G	USA	CV862	6SH7	USA	CV594
6H6	Cossor		6L6	USA	CV1948		Ferranti	
	Ferranti			Ferranti			Cossor	
				Cossor			USA	
6H6G	USA	CV1929	6L6G	USA	(CV1947)	6SH7GI	USA	CV595
	Ferranti			Thorn			USA	
	Tungfram			Tungfram		6SH7L	Ferranti	CV5067
6H6GI	USA	CV1931		Ferranti		6SJ7	USA	CV591
	Ferranti			Cossor			Ferranti	
	Thorn		6L6GA	USA	CV2817		Cossor	
	Cossor			Thorn			USA	
6H6GI/G	USA	CV1931		Tungfram		6SJ7G	Ferranti	CV590
6J4	USA	(CV1763)				6SJ7GI	USA	CV592
6J4WA	USA	CV5029	6L6GIY	USA	CV5306		Tungfram	
			6L6WGA	USA	CV3618	6SJ7WGI	USA	CV3619
6J5	USA	CV1933	6L6WGB	USA	CV2796			
	Ferranti		6L6Y	USA	CV5118	6SJ77	RCA	CV591
	Cossor		6L7	USA	CV1951			CV866
	USA	(CV1932)		Cossor		6SK7	USA	CV1981
6J5G	Cossor						Ferranti	
	Mullard		6L7G	USA	CV1950	6SK7GI	USA	CV1982
	Tungfram			Tungfram			Ferranti	
	Ferranti		6L18	USA	CV1899		Tungfram	
6J5GI	USA	(CV1934)	6L19	Mazda	CV1850	6SK7GI/G	Cossor	CV1982
	Ferranti		6L34	Mazda	(CV417)		USA	
	Cossor		6LD3	Mazda	(CV3882)			
	Tungfram							
6J5GI/G	USA	(CV1934)	6LD20	Mazda	CV1920	6SL7GI	USA	CV1985
6J6	USA	(CV858)	6N5	USA	CV843		Ferranti	
			6N6	USA	CV1954		Thorn	
6J6W	USA	CV2843	6N6G	USA	CV1953		Cossor	
6J6WA	USA	(CV4031)	6N7	USA	CV1957	6SL7WGI	USA	CV3985
6J7	USA	CV1936		Ferranti		6SN7GT	USA	(CV1988)
	Ferranti		6N7G	USA	CV1956		Thorn	
	Cossor		6N7GI	USA	CV1958		Tungfram	
6J7G	USA	(CV1935)		Ferranti			Ferranti	
	Ferranti		6P5GI/G	RCA	CV1819		Cossor	
	Cossor		6P7G	RCA	CV864	6SN7WGI	USA	CV3627
	Tungfram		6P25	Mazda	CV1853	6SQ7	USA	CV1990
6J7GI	USA	(CV1937)					Ferranti	
	Ferranti		6Q4	Mullard	CV1886		Cossor	
	Tungfram			Philips		6SQ7GI	USA	CV1991
			6Q5G	USA	CV1815		Ferranti	
6J8G	USA	-CV859	6Q7	USA	CV588	6SQ7GI/G	Tungfram	CV1991
	Tungfram		6Q7G	USA	(CV587)		USA	
				Cossor				
6J11	RCA	CV9836		Brimar		6SR7	USA	CV867
6K4	USA	CV2855		Tungfram		6SS7	USA	CV1993
6K5G	USA	CV860		Ferranti			Ferranti	
6K5GT	USA	CV861	6Q7GI	USA	(CV589)		Cossor	
				Ferranti		6SI7	USA	CV1996
6K5GI/G	USA	CV861		Tungfram		6SI7G	USA	CV1995
6K6G	USA	CV1938		Cossor		6T4	USA	CV3808
	Ferranti							